

Welcome to the Windows ME Installation Guide

Driver Installation


Follow the steps below to install Window 98se driver of USB-Serial Converter:

1. Power on your computer and make sure that the USB port is enabled and working properly.
2. Plug in the USB-Serial Converter into the USB port and run the **Add New Hardware Wizard** to assist you in setting up the new device. Click **Next** to continue.



3. Insert the USB-Serial Converter software driver into the CD-ROM drive and click Next to continue and click to search driver from a specify location. Browse to the location where the inf-File is placed.







4. Windows will detect the driver and shows the **USB HS Serial Converter**. Click Next to continue installation.



- 5. Click Next to continue and let Windows copy the needed files to your hard disk.
- 6. When Windows finished installing the software,click Finish.



7. See the Device Manager to check the **USB HS Serial Converter**.



Changing the COM Port Number


1. From "**Device Manager**", select "**View devices by type**", then "**Ports (COM & LPT)**".
2. Select the USB serial port and click **Properties**.
3. Select the "**Port Settings**" tab, then click "**Advanced**". Choose the required COM port number from the list and click **OK**.



Notes

If a modem is attached to the USB serial port when the port number is changed, it will continue to work under the new port number.

If a modem had been attached to the USB serial port but was not attached when the port number was changed, it will not work when re-attached under the new port number. In this case, the modem must be removed from the system and re-installed.

In general, if there are devices in the system which have been attached previously to the USB serial port, they may not work after the port number has been changed. If this is true, remove the device from the system and re-install it.





Uninstalling the Driver Program

If you want to remove the USB-Serial Converter driver program, you can uninstall it by following the steps below:

1. Unplug the USB-Serial Converter from your PC.
2. Run the "**Ftdiunin.exe**" program from the software CD-ROM, then Click "continue" to remove the USB-Serial Converter driver program.
3. Click "Finish", then reboot the PC.

